



# GL520MG

## LTE Cat M1/NB2 waterproof GNSS tracker with up to 7 years standby time

140g (4.94oz) 160g (5.64oz) (magnetic case mounting version)

87 × 51 × 30mm 3.43"(L) × 2.01"(W) × 1.18"(H) 87 × 51 × 33.5mm 3.43"(L) × 2.01"(W) × 1.32"(H) (magnetic case mounting version)

-20°C ~ +60°C

**----**)

3 CR123A lithium batteries, 1400 mAh

#### Standby Time:

1 Report/ Day (GNSS on) 5 Years 1 Report/ Day (Cell ID Only) 7 Years 

LTE Cat M1/NB2 with 2G Fallback

Rapid & Covert Installation

7 Years Standby Time

**OTA Control** 

Scheduled Timing Report

Geo-fences

Waterproof

Vibration Feedback

Low Power Alarm

Wakeup Report

Motion Detection

Automatic Mode Switching

Temperature Monitoring

**Tamper Detection** 

Magnetic mounting (Optional)

Use with Animal Collars

The GL520MG is an easy-to-deploy asset tracker built on Queclink's innovative power management technology. It lasts for up to seven years and features one of the longest battery lives among devices of its size in the market. The built-in light sensors make the product sensitive to tamper attempts and its waterproof design allows it to be used in harsh environments. With internal temperature and light sensors, the product is ideal for a wide range of environmental monitoring applications such as cold chain logistics, warehouse management, cargo trucking, highvalue static asset monitoring and more. The GL520MG supports several mounting alternatives which use unique clip on design to securely attach the device to any asset.



#### GL520MG

| Region    | Operating Band   | GNSS Type                          | Position Accuracy (CEP) | Certificate |
|-----------|--|------------------------------------|-------------------------|-------------|
| Worldwide | Cat M1: LTE-FDD: B1/B2/B3/B4/B5/B8/ B12/B13/B18/B19/B20/B25/B26/ B27/B28/B66/B85 Cat NB2: LTE-FDD: B1/B2/B3/B4/B5/B8/ B12/B13/B18/B19/B20/B25/B28/ B66/B71/B85 EGPRS: 850/900/1800/1900MHz | u-blox All-in-One<br>GNSS receiver | Autonomous: < 2.5m      | TBD         |

## **Appearance**



### Interfaces

| Power Button Used for power on/off and working status checking |               |
|--|---------------|
| LTE Antenna  | Internal only |
| GNSS Antenna   | Internal only |
| LED Indicators   | GNSS, Status  |

### **Air Interface Protocol**

| Command Set                    | @Track protocol command   |
|--------------------------------|---|
| Transmit Protocol              | TCP, UDP, SMS   |
| Working Modes                  | Power saving mode for long standby time<br>Continuous mode for emergency tracking |
| Scheduled Timing Report        | Report position and status at preset time intervals                               |
| Geo-fences                     | Support up to 20 internal geo-fence regions                                       |
| Low Power Alarm                | Alarm when internal battery is low  |
| Wakeup Report                  | Report when the device wakes up   |
| Motion Detection               | Motion detection based on internal 3-axis accelerometer                           |
| Reporting Frequency Adjustment | Intelligent adjustment of reporting frequency                                     |
|                                |   |

### Accessories



## **GL500M Magnetic Mounting Bracket**

It's used for mounting GL500 and GL501 LTE series



## **GL500M Mounting Bracket**

It's used for mounting GL500 and GL501 LTE series



### **GL500M Battery Pack**

Lithium Battery Pack 1400mAh 9V 12.6Wh 3-Cells